


7. How to set the output and register value of xLogic CPU via ELC-MD204I ?


Communication parameter configuration in TP200 software(ELC-Md204L config soft).

PLC selection:




A. Read input status

Input status setting (I1)




B .Read current value of registers including REGs(current value of blocks), AI(analog input values),AM ,AF(analog flags),AQ(analog output values).

REG0 (register 1)



C. Read output status (M, F status also can be read in the same way!)


Q1 status




D. Change the output status via ELC-MD204's panel key. (Digital flag-F status also can be set in the same way)




Change Q2 status via the button of HMI (Note: the output block/F block cannot take part in the logic of xLogic program, that means the **input pin** cannot be linked with other blocks while programming, just like following figure shows, Q2 and F1 can be set via Master (ELC-MD204L), however Q1 can not be set via Master).





E. Set register value via ELC-MD204L.

Note: Register value means the current value of the block ,it's not the parameter value in the dialog box.Next let's take a counter as example




The REG0 value is to show the current counter value of the block (B001) ,it's not the value of "On Threshold"/"Off Threshold".

Hereunder we take an example to show you how to set the "On Threshold"/"Off Threshold" Value.


We first shall make a programme in the xLogicsoft ,we can use the "reference" function and set AQ1 and AQ2 value and indirectly to change the

"On Threshold"/"Off Threshold" value.




Set AQ1 (the address configured in the below figure is for economic/ standard ELC-18) value via ELC-MD204L(AQ also can be replaced by AF in above figure)

Below is configuration in the ELC-MD204L software



Set AQ2 value via ELC-MD204L



Note: Refer to the "Modbus communication instruction" file for the register address.

8. If xLogic CPU shall be required to serve as master in modbus/RS485 communication network,how to make it ?

You need refer to the instruction of "Modbus Read" and "Modbus Write" function blocks in user manual or the help file of xLogicsoft .